

Step 1: Cut the Carpet Seam: Overlap the edges of the carpet leaving about 2 inches of excess carpet at the wall. Snap a chalk line on the back of the overlapped carpet edges and trim a straight edge to ensure a straight seam.

STEP 2: Overlap the straight edges and use a row cutter to cut the bottom piece. The edge of the top piece should be your guide in cutting the seam to fit.

Step 3: Cut a length of seaming tape and center it under the seam. Make sure the adhesive side of the tape is facing up and the carpet seams butt up against each other. Use a seaming iron to melt the adhesive by slowly pulling the iron down the tape. Once the adhesive is melted, immediately press the carpet edges together over the tape. Roll over the seam with a rolling pin (TRACTOR) TO BLEND CARPET FIBERS.